

HyLite OptiMax™ LED Tube Lights Installation/Retrofit Guide

Note: If the Tube is installed as Type B, the Luminaire, once modified as a Retrofit Fixture, will no longer operate Fluorescent Lamps. Not Suitable for Use with Dimmer.


Thank you for purchasing HyLite OptiMax™ LED Tube Light and for investing in the future of eco-friendly products. By selecting HyLite OptiMax™ LED Tube Light you have chosen a High-quality, Eco-friendly product that is designed for years of Dependable Performance. We trust you will experience years of Reliable Service from it. This guide explains the Steps necessary to Install or Retrofit the T8/T10/T12 Tube Lights to ensure Optimal Performance. This guide is for reference only and is intended for Qualified Electricians or Lighting Technicians. HyLite OptiMax™ LED Tube Lights are intended to Retrofit Maximum Four Lamps, Surface Mount, or Non-IC Recessed Mount Fluorescent Luminaries that use Straight Tubular Tube Lights.

Warning - Important Safety Instructions

- Read and Understand the detailed Installation Instructions before installing the HyLite OptiMax™ LED T8 Tube Light.
- HyLite OptiMax™ LED T8 Tube Lights are designed to work with Electronic/Magnetic Ballasts (Check the Ballast Compatibility List) or AC Direct Wire. Works with Single-end (either side) and/or Double-end Power Input. Risk of Fire or Electric Shock. Read and Understand all Installation Instructions before installing HyLite OptiMax™ LED T8 Tube Lights. Use in Dry or Damp locations only. Do not use where directly exposed to water or weather. Non-submergible (not water tight).
- Disable all Power to the Fixture before Inspection, Installation, or Removal. Failure to do so will create a Hazardous and Fatal Working Environment.
- Do Not Make or Alter any Open Holes in an Enclosure of Wiring or Electrical Components during Installation.
- Do Not Open No User Serviceable Parts inside.


WARNING:

- a. Risk of Fire or Electric Shock. LED Retrofit Kit Installation requires knowledge of Luminaires Electrical Systems. If not Qualified, DO NOT attempt Installation. Contact a Qualified Electrician.
- Risk of Fire or Electric Shock. Install this Kit only in the Luminaires that have the construction features and dimensions shown in the photographs and/or drawings and where the Input Rating of the Retrofit Kit does not exceed the Input Rating of the Luminaire.
- DO NOT make or alter any open holes in an enclosure of Wiring or Electrical Components during Kit Installation
- To prevent Wiring Damage or Abrasion, DO NOT Expose Wiring to edges of Sheet Metal or other Sharp Objects.
- Installers should not Disconnect existing Wires from Lampholder Terminals to make new Connections at Lampholder Terminals. Instead Installers should Cut existing Lampholder Leads away from the Lampholder and make new Electrical Connections to Lampholder Lead Wires by employing applicable Connectors.
- For a Linear Tubular LED Lamp Conversion, there shall be text or a Diagram showing how the supply Connections were made to the Lampholders so the correct Connections will be made to the Lamp when the Lamp is Installed or Replaced.
- This Retrofit Kit is accepted as a component of a Luminaire where the suitability of the combination shall be determined by Authorities having JURISDICTION.




Instructions:

- 1. Switch-off Power to the Luminaire.
- 3. Remove the existing Fluorescent Lamps from the Luminaire.
- 5. Install Diffuser (if removed in step 2)
- 2. Remove Diffuser (if provided).
- 4. Install the LED Tube Lamp.
- 6 Switch on Power to the Luminaire
- 7. Before Installation, please check Specifications for the most Current Ballast Compatibility List. If not Compatible, please insert LED Tubes according to Type B Installation Instructions.










2. REMOVE EXISTING TUBE LAMP(S)

- a. Remove Troffer Lens, if present.
- Remove existing Fluorescent Tube by Rotating One-quarter turn and sliding Lamp(s)
- Remove Ballast Cover. (Cover may be secured with Screws or Tabs).









3 a. RETROFIT LUMINAIRE - Retrofit Luminaire with Inductive Ballast









Connect two Wires to Branch Circuit L and N according to the figure on the left.


N

Ballast



Disconnect the Wires between Starter and Ballast according to the figure on the right





5. RESTORE THE POWER OF LUMINAIRE

Restore Power to Circuit/Luminaire and test Light. If necessary, adjust position of LED Tube, and enjoy your new HyLite OptiMax™ LED Tube!